


SINYO.#	OEM.#	Description
STDI01	SM-04-VRF	Display Board
STDI02	SM-04-UL	Step LCD Display Board
STDI03	SM-04-VSD	DOT Matrix Indicator Display Board
STDI04	SM-04-VL16/A	Hall Display Board
STDI05	SM-04-VSC	Display Board
STDI06	SM-04-VLB3	LCD Vertical Display Board
STDI07	SM-04-HRC	DOT Matrix Indicator Display Board
STDI08	SM-04-HRD	DOT Matrix Indicator Display Board
STDI09	SM-04-HSC	DOT Matrix Indicator Display Board
STDI10	SM-04-VRJ	DOT Matrix Indicator Display Board
STDI11	SM-04-HREB	Super Large Screen Dot Matrix Display Board
STDI12	SM-04-HREC	Super Large Screen Dot Matrix Display Board
STDI13	SM-04-ND	Call Display Board
STDI14	SM-04-V7	Super Thin Indicator Display Board
STDI15	SM-04-VRH	Super Thin Indicator Display Board
STDI16	SM-04-V7/B	16 Segment Indicator Display Board
STDI17	SM-04-V7/C	16 Segment Indicator Display Board
STDI18	SM-04-H7/A	Parallel Indicator Display Board
STDI19	SM-04-H7/B	Parallel Indicator Display Board
STDI20	SM-04-HR/G	Parallel Indicator Display Board
STDI21	SM-04-HR/H	Parallel Indicator Display Board
STDI22	SM-04-VS-E	Parallel Indicator Display Board



SINYO.#	OEM.#	Description
STPCB01	SM-01-F5021	Main Controller PC Board
STPCB02	SM.01PA/D	Main Controller PC Board
STPCB03	SM-01-CD/A	Main Controller PC Board
STPCB04	SM-01-DP-C	Main Controller PC Board
STPCB05	SM-01-HO/B	Home Hydraulic Controller PC Board
STPCB06	SM-01-HO/C	Home Hydraulic Controller PC Board
STPCB07	SM-02-D	Car Controller PC Board
STPCB08	SM-03-D	Command PC Board

