



| SINYO.# | OEM.# | Description                                       |
|---------|-------|---------------------------------------------------|
| LSBT01  | KA142 | Push Button, Installation Hole Size: $\Phi 36.5$  |
| LSBT02  | KA141 | Push Button, Installation Hole Size: 40 X 40      |
| LSBT03  |       | Push Button                                       |
| LSBT04  |       | Push Button, Red                                  |
| LSBT05  | KA31G | Push Button, Installation Hole Size: 33 X 33      |
| LSBT06  | AK-25 | Push Button, Installation Hole Size: 40 X 30 X 17 |
| LSBT07  |       | Push Button, Round                                |


| SINYO.# | OEM.# | Description                                                                                                        |
|---------|-------|--------------------------------------------------------------------------------------------------------------------|
| LSWR01  |       | Door Roller, $\Phi 65 \times 13 \times 6202$ (S-Slot)                                                              |
| LSWR02  |       | Door Roller, $\Phi 33 \times 10 \times M10$                                                                        |
| LSWR03  |       | Door Roller, $\Phi 68 \times 14 \times 6202$                                                                       |
| LSWR04  |       | Door Roller, Nylon, $\Phi 56 \times 14 \times 6201$                                                                |
| LSWR05  |       | Door Roller, $\Phi 56 \times 14 \times 6201$                                                                       |
| LSWR06  |       | Door Roller With Axle, $\Phi 65 \times 13 \times M12$                                                              |
| LSWR07  |       | Guide Shoe Roller, $\Phi 195 \times 38 \times 2-6003$                                                              |
| LSWR08  |       | Guide Shoe Roller, $\Phi 235 \times 30 \times 2-6004$                                                              |
| LSWR09  |       | Guide Shoe Roller, $\Phi 125 \times 22 \times 6303$                                                                |
| LSWR10  | PB226 | Roller Guide Shoe Assembly,<br>Roller: $\Phi 195 \times 38 \times 2-6003$ ,<br>Mounting Hole: $\Phi 140 \times 70$ |


| SINYO.# | OEM.# | Description                   |
|---------|-------|-------------------------------|
| LSDH01  |       | Car Door Hanger, JJ=800-1100  |
| LSDH02  |       | Car Door Hanger, L=400, L=500 |
| LSDH03  |       | Car Door Hanger, L=400, L=500 |

| SINYO.# | OEM.# | Description                                                |
|---------|-------|------------------------------------------------------------|
| LSGS01  |       | Guide Shoe Insert,<br>One 120 X 22 X 7, Two 120 X 20 X 6   |
| LSGS02  |       | Guide Shoe Insert,<br>One 120 X 27.5 X 7, Two 120 X 25 X 6 |

| SINYO.# | OEM.# | Description                 |
|---------|-------|-----------------------------|
| LSDS01  |       | Door Slider, 62 X 40 X 11.5 |
| LSDS02  |       | Door Slider, 33 X 56 X 12   |
| LSDS03  |       | Door Slider                 |

| SINYO.# | OEM.# | Description |
|---------|-------|-------------|
| LSDV01  |       | Door Vane   |





| SINYO.# | OEM.#    | Description       |
|---------|----------|-------------------|
| LSL001  | 161D-G01 | Door Lock(Left)   |
| LSL002  |          | Car Door Lock     |
| LSL003  |          | Door Lock Contact |
| LSL004  | MSA-13   | Door Lock Contact |
| LSL005  | MSA-2    | Door Lock Contact |
| LSL006  |          | Power Lock        |

| SINYO.# | OEM.#       | Description     |
|---------|-------------|-----------------|
| LSSS01  | MPS-1600-LG | Leveling Sensor |

| SINYO.# | OEM.#     | Description       |
|---------|-----------|-------------------|
| LSTT01  | DOA-100   | Service Tool      |
| LSTT02  | OPP-2000  | Service Tool      |
| LSTT03  | MSEC-400M | Stop Announcement |

| SINYO.# | OEM.#             | Description |
|---------|-------------------|-------------|
| LSEN01  | PKT1040-1024-C15C | Encoder     |
| LSEN02  | DPD-05            | Encoder     |

| SINYO.# | OEM.#       | Description |
|---------|-------------|-------------|
| LSDM01  | IM-050B080A | Door Motor  |


| SINYO.# | OEM.#    | Description                            |
|---------|----------|----------------------------------------|
| LSBM01  | FB-1035B | Fan, Mounting Hole: 380 X 90, AC: 220V |
| LSBM02  | 2R23336A | Brake Coil                             |

| SINYO.# | OEM.# | Description              |
|---------|-------|--------------------------|
| LSFI01  | ACVF  | Door Motor Inverter, 24V |

| SINYO.# | OEM.#  | Description         |
|---------|--------|---------------------|
| LSCT01  | GMD-32 | Contactor, DC: 110V |
| LSCT02  | GMD-22 | Contactor, DC: 48V  |
| LSCT03  | GMC-9  | Contactor, DC: 110V |

| SINYO.# | OEM.#     | Description       |
|---------|-----------|-------------------|
| LSDI01  | DCI-230   | Display Board     |
| LSDI02  | DHI-221   | HOP Display Board |
| LSDI03  | EISEG-205 | HOP Display Board |
| LSDI04  | EISEG-221 | Display Board     |
| LSDI05  | EISEG-106 | Display Board     |
| LSDI07  | DCI-210   | Display Board     |





LSDI08




LSDI10




LSDI09




LSDI11




LSDI12




LSDI13




LSDI14



LSDI15



LSDI16



LSDI17

| SINYO.# | OEM.# | Description |
|---------|-------|-------------|
|---------|-------|-------------|

|        |         |               |
|--------|---------|---------------|
| LSDI08 | DCI-260 | Display Board |
|--------|---------|---------------|

|        |           |               |
|--------|-----------|---------------|
| LSDI09 | EISEG-208 | Display Board |
|--------|-----------|---------------|

|        |          |               |
|--------|----------|---------------|
| LSDI10 | DHI-430N | Display Board |
|--------|----------|---------------|

|        |          |               |
|--------|----------|---------------|
| LSDI11 | DCM-115N | Display Board |
|--------|----------|---------------|

|        |         |               |
|--------|---------|---------------|
| LSDI12 | DCM-12X | Display Board |
|--------|---------|---------------|

|        |                |               |
|--------|----------------|---------------|
| LSDI13 | CPIPCB 1R02483 | Display Board |
|--------|----------------|---------------|

|        |           |               |
|--------|-----------|---------------|
| LSDI14 | EISEG-207 | Display Board |
|--------|-----------|---------------|

|        |         |               |
|--------|---------|---------------|
| LSDI15 | IR02661 | Display Board |
|--------|---------|---------------|

|        |           |               |
|--------|-----------|---------------|
| LSDI16 | EISEG-260 | Display Board |
|--------|-----------|---------------|

|        |         |               |
|--------|---------|---------------|
| LSDI17 | DCM-10X | Display Board |
|--------|---------|---------------|

|        |           |               |
|--------|-----------|---------------|
| LSDI18 | EISEG-107 | Display Board |
|--------|-----------|---------------|

|        |          |               |
|--------|----------|---------------|
| LSDI19 | PHI-500B | Display Board |
|--------|----------|---------------|

|        |         |               |
|--------|---------|---------------|
| LSDI20 | DHI-150 | Display Board |
|--------|---------|---------------|

|        |         |               |
|--------|---------|---------------|
| LSDI21 | DHM-12X | Display Board |
|--------|---------|---------------|

|        |         |               |
|--------|---------|---------------|
| LSDI22 | DHM-143 | Display Board |
|--------|---------|---------------|

|        |         |               |
|--------|---------|---------------|
| LSDI23 | DHM-100 | Display Board |
|--------|---------|---------------|

|        |          |               |
|--------|----------|---------------|
| LSDI24 | DC-LED-2 | Display Board |
|--------|----------|---------------|

|        |           |               |
|--------|-----------|---------------|
| LSDI25 | EISEG-212 | Display Board |
|--------|-----------|---------------|

|        |            |               |
|--------|------------|---------------|
| LSDI26 | EISEG-212A | Display Board |
|--------|------------|---------------|

|        |         |               |
|--------|---------|---------------|
| LSDI27 | DHI-11X | Display Board |
|--------|---------|---------------|

|        |        |               |
|--------|--------|---------------|
| LSDI28 | INV VD | Display Board |
|--------|--------|---------------|

|        |           |               |
|--------|-----------|---------------|
| LSDI29 | EISEG-108 | Display Board |
|--------|-----------|---------------|

|        |          |               |
|--------|----------|---------------|
| LSDI30 | DHI-221N | Display Board |
|--------|----------|---------------|

|        |           |               |
|--------|-----------|---------------|
| LSDI31 | EIDOT-305 | Display Board |
|--------|-----------|---------------|

|        |       |               |
|--------|-------|---------------|
| LSDI32 | HDF-1 | Display Board |
|--------|-------|---------------|

|        |         |               |
|--------|---------|---------------|
| LSDI33 | DHI-201 | Display Board |
|--------|---------|---------------|

|        |         |               |
|--------|---------|---------------|
| LSDI34 | DCM-102 | Display Board |
|--------|---------|---------------|

|        |          |               |
|--------|----------|---------------|
| LSDI35 | DCM-116N | Display Board |
|--------|----------|---------------|

|        |         |               |
|--------|---------|---------------|
| LSDI36 | DHI-461 | Display Board |
|--------|---------|---------------|

| SINYO.# | OEM.# | Description |
|---------|-------|-------------|
|---------|-------|-------------|

|         |         |          |
|---------|---------|----------|
| LSPCB01 | CJB-100 | PC Board |
|---------|---------|----------|

|         |         |          |
|---------|---------|----------|
| LSPCB02 | DCD-201 | PC Board |
|---------|---------|----------|


|         |         |          |
|---------|---------|----------|
| LSPCB03 | DCD-230 | PC Board |
|---------|---------|----------|

|         |         |          |
|---------|---------|----------|
| LSPCB04 | DHG-160 | PC Board |
|---------|---------|----------|

|         |         |          |
|---------|---------|----------|
| LSPCB05 | DHG-161 | PC Board |
|---------|---------|----------|

|         |         |          |
|---------|---------|----------|
| LSPCB06 | DHL-270 | PC Board |
|---------|---------|----------|

|         |         |          |
|---------|---------|----------|
| LSPCB07 | DOC-101 | PC Board |
|---------|---------|----------|



LSDI18




LSDI19




LSDI20



LSDI21




LSDI22



LSDI24




LSDI25



LSDI26




LSDI27




LSDI28




LSDI29



LSDI30



LSDI31




LSDI32




LSDI33



LSDI34



LSDI35



LSDI36



LSPCB01



LSPCB02



LSPCB03



LSPCB04



LSPCB05



LSPCB06




LSPCB07




LSPCB08




LSPCB09




LSPCB10




LSPCB11



LSPCB12



LSPCB13



LSPCB14


| SINYO.# | OEM.#                              | Description |
|---------|------------------------------------|-------------|
| LSPCB08 | DOC-103                            | PC Board    |
| LSPCB09 | DOC-130                            | PC Board    |
| LSPCB10 | DOC-131                            | PC Board    |
| LSPCB11 | DOC-200                            | PC Board    |
| LSPCB12 | DOM-110A                           | PC Board    |
| LSPCB13 | DOM-130A                           | PC Board    |
| LSPCB14 | DOP-130                            | PC Board    |
| LSPCB15 | DPC-121                            | PC Board    |
| LSPCB16 | DPC-130                            | PC Board    |
| LSPCB17 | DPP-101                            | PC Board    |
| LSPCB18 | DCD-221                            | PC Board    |
| LSPCB19 | DCL-244                            | PC Board    |
| LSPCB20 | DOC-120                            | PC Board    |
| LSPCB21 | DOC-211                            | PC Board    |
| LSPCB22 | DPP-131                            | PC Board    |
| LSPCB23 | HBDC                               | PC Board    |
| LSPCB24 | INV-FIO                            | PC Board    |
| LSPCB25 | INV-SDCL                           | PC Board    |
| LSPCB26 | LOA-410KB G02                      | PC Board    |
| LSPCB27 | OPB-100                            | PC Board    |
| LSPCB28 | SMCB-3000CI                        | PC Board    |
| LSPCB29 | WTCT5911                           | PC Board    |
| LSPCB30 | SEMR-100                           | PC Board    |
| LSPCB31 | BL2000 CZB-V8                      | PC Board    |
| LSPCB32 | BL2000-CZB-V8.0/<br>BL2000-CEB-2.0 | PC Board    |
| LSPCB33 | DHG-162                            | PC Board    |
| LSPCB34 | DOR-131                            | PC Board    |
| LSPCB35 | DOC-220                            | PC Board    |
| LSPCB36 | DCL-243                            | PC Board    |
| LSPCB37 | HS6T 1R02477-B                     | PC Board    |
| LSPCB38 | FX-MPU-0                           | PC Board    |
| LSPCB39 | EOC-200                            | PC Board    |
| LSPCB40 | INV-MPU-2                          | PC Board    |
| LSPCB41 | POC-300                            | PC Board    |
| LSPCB42 | DOP-112                            | PC Board    |
| LSPCB43 | DHL-250                            | PC Board    |
| LSPCB44 | EOC-300                            | PC Board    |
| LSPCB45 | DHP-100                            | PC Board    |
| LSPCB46 | DPB-100A                           | PC Board    |
| LSPCB47 | DHF-121                            | PC Board    |
| LSPCB48 | OPB-2000SPA                        | PC Board    |
| LSPCB49 | DCD-31M                            | PC Board    |
| LSPCB50 | DOP-122                            | PC Board    |
| LSPCB51 | DOP-111                            | PC Board    |




LSPCB15



LSPCB16




LSPCB17




LSPCB18



LSPCB19



LSPCB20



LSPCB21



LSPCB22




LSPCB23



LSPCB24



LSPCB25



LSPCB26



LSPCB27



LSPCB28



LSPCB29



LSPCB30



LSPCB31




LSPCB32



LSPCB33



LSPCB34



LSPCB35



LSPCB36



LSPCB37



LSPCB38



LSPCB39



LSPCB40



LSPCB41



LSPCB42



LSPCB43



LSPCB44



LSPCB45



LSPCB46




LSPCB47



LSPCB48



LSPCB49



LSPCB52



LSPCB54



LSPCB56




LSPCB58




LSPCB59




LSPCB61




LSPCB62



LSPCB53



LSPCB55




LSPCB57




LSPCB60

| SINYO.# | OEM.#                  | Description |
|---------|------------------------|-------------|
| LSPCB52 | DOP-310                | PC Board    |
| LSPCB53 | POS-300                | PC Board    |
| LSPCB54 | DPP-150                | PC Board    |
| LSPCB55 | DPC-123                | PC Board    |
| LSPCB56 | DOC-103                | PC Board    |
| LSPCB57 | DOC-101                | PC Board    |
| LSPCB58 | DHG-150                | PC Board    |
| LSPCB59 | DCL-240                | PC Board    |
| LSPCB60 | DCL-200                | PC Board    |
| LSPCB61 | DES-100                | PC Board    |
| LSPCB62 | DOC-132                | PC Board    |
| LSPCB63 | DOC-142                | PC Board    |
| LSPCB64 | DOJ-110                | PC Board    |
| LSPCB65 | DOJ-130                | PC Board    |
| LSPCB66 | DOL-210                | PC Board    |
| LSPCB67 | DOP-300                | PC Board    |
| LSPCB68 | DOR-210                | PC Board    |
| LSPCB69 | DOR-220                | PC Board    |
| LSPCB70 | DOR-232                | PC Board    |
| LSPCB71 | DOS-100                | PC Board    |
| LSPCB72 | DPC-100                | PC Board    |
| LSPCB73 | DPC-113                | PC Board    |
| LSPCB74 | DPC-140                | PC Board    |
| LSPCB75 | DPP-111                | PC Board    |
| LSPCB76 | DPP-140                | PC Board    |
| LSPCB77 | DPP-200                | PC Board    |
| LSPCB78 | DPP-310                | PC Board    |
| LSPCB79 | DPP-320                | PC Board    |
| LSPCB80 | MCB2001CI REV2.4       | PC Board    |
| LSPCB81 | MCB3000CI REV1.6       | PC Board    |
| LSPCB82 | WTCT 5911              | PC Board    |
| LSPCB83 | DCD-23                 | PC Board    |
| LSPCB84 | TPS-5037-LG AEG01C126B | PC Board    |
| LSPCB85 | 3R49868B               | PC Board    |
| LSPCB86 | EPU-100                | PC Board    |
| LSPCB87 | DOR-110A               | PC Board    |
| LSPCB88 | CRB-100                | PC Board    |



LSPCB63




LSPCB64




LSPCB65



LSPCB68



LSPCB71



LSPCB72



LSPCB75



LSPCB80




LSPCB83




LSPCB85




LSPCB88




LSPCB66



LSPCB69



LSPCB73



LSPCB76




LSPCB78




LSPCB81




LSPCB86




LSPCB67



LSPCB70



LSPCB74




LSPCB77



LSPCB79



LSPCB82



LSPCB84



LSPCB87